

Using the X-Rite Intellitrax-2 on MeasureColor 16.2 or 16.1

When installing or updating MeasureColor 16.2 or 16.1 is set-up to work with the Intellitrax-1. However you can use the Intellitrax-2 by exchanging two files from the MeasureColor 4 folder.

Close MeasureColor if it is running.

Download the correct files from the prerequisite folder on our website which can be found here:

<http://support.colorware.eu/downloads/prerequisites/>

MeasureColor 16.1.xx	Intellitrax-2	ITX2_for_MeasureColor_16_1.ZIP
MeasureColor 16.2.xx	Intellitrax-2	ITX2_for_MeasureColor_16_2.ZIP

Unzip the file (right mouse click)

Right mouse click the files and look at their properties. Probably they will be blocked because they came from a different PC. Tick the box to unblock them and click "apply".

Navigate to the MeasureColor Client folder:

64-bit PC	C:\Program Files (x86)\MeasureColor 4\Client
32-bit PC	C:\Program Files\MeasureColor 4\Client

Locate the file "ATSIIInst.dll" and replace this with the file in the downloaded folder with the same name.

Navigate to the Plug-ins folder.

Locate the file "ItxDevicePlugin.dll". Remove it from the directory. Now copy the file "Itx2DevicePlugin.dll" from the download to the plug-ins folder.

Start MeasureColor and recalibrate the Intellitrax-2 before measuring.

Please note that these steps should be checked after an update as well.